

Update Notes for Kiwi-1000 v Prog 1.60 & Boot 2.00

This update needs files to be run in the correct order.

Take note of the current release at normal power on. It will display on the 3 digit display for 1 second when the synth is powered on. The first two digits are the Program Release and the last is the Bootloader release. For this version once installed this will read '162'

Files can be played into the Kiwi-1000 using MidiOX or similar.

- 1) While pressing the MODE button switch on the power.
- 2) Play in the file K1000_Boot_v200_Build11.SYX and wait until the display shows ' Gd' (Good)
- 3) While pressing the MODE button cycle the power
- 4) Play in the file K1000_Prog_v160_Build1.SYX
- 5) Once the display shows ' Gd' cycle the Power

The release digits will show 16 and 2 (Prog v160 & Boot v200)

Included with the update is the 1000 factory tone set for Set 0. This file contains 1000 tones.